ı	
ℛ	`
(X	,

- アーク 鋼板セルを連結する弧状の部分。
- 2 **アーク溶接** 母材と溶接棒の間に電流を流してアーク放電を発生させ、その 熱で金属を溶接する方法。
- 3 アーク溶接鋼 帯鋼あるいは鋼板を管状に形成し、アーク溶接で仕上げた鋼管。 管
- 4 AASHTO 土質分 アメリカ合衆国で、道路の路床、路盤材料の分類に用いられて 類法 いる規格。
- 5 アースアンカ 構造物を地盤に固定するために、構造物にワイヤーなどの引張 ー 材を締結し、引張材の他端を地盤に固定する構造用様式において、地盤に固定する方式の一つで、アンカーが土砂中にあるものをいう。岩盤中であればロックアンカーという。
- 6 アースオーガ 地盤に穴を掘削するための機械。
- 7 アースドリル 地盤に穴をあける機械。
- 8 アーセル数 浅海波の非線形効果の程度を表す無次元数。
- 9 アーリントン コンクリート版の曲げ応力の計算式。公式

arc A member connecting steel plate cells.

arc welding A kind of electric welding method which uses a welding power supply to

create an electric arc between an electrode and the base material to melt the

metals at the welding point.

arc welded steel

pipe

A steel pipe made from a steel plate by bending it into a tubular shape and

welding the two edges together by arc welding.

AASHTO soil classification

system

A classification method of soils in the United States that is employed for the specifications of soil materials used for subgrade and sub base course of

highways.

tie-back anchor One of the methods to fasten a structure on the ground by pulling the structure

by wires that interconnect the structure and anchor placed underground.

When the anchor is buried in soil, the fastening method is called the earth anchor, while it is called the rock anchor when the anchor is placed in rock.

earth auger A type of heavy construction equipment used to make a hole in the ground.

earth drill A type of heavy construction equipment to drill the ground.

Urcell number Non-dimensional parameter that indicates the magnitude of nonlinearity of

shallow water waves.

Arligton equation An equation to calculate bending stresses in a concrete slab.

.

あ

10 **亜鉛電極法** 亜鉛電極を鋼材に取り付け鋼材が有する電位を腐食が生じない 電位(防食電位)まで下げることにより腐食を防止または抑制 する方法。

11 **青潮** 海域において、夏季あるいは早秋に貧酸素状態となった底層水が上層に運ばれ、海水が青色を呈し漁業被害を招く現象。

12 **赤潮** 海域においてプランクトンが異常増殖して海水が赤褐色を呈する現象。魚介類の発死等の被害を招く。

13 **浅い基礎** 根入れ幅比がおよそ1以下で、テルツァーギの浅い基礎に関する支持力公式が適用できるような基礎。現在では杭等を用いない直接基礎とほぼ同義で使われている。

14 アジア天気図 気象庁が作成し一日4回(3、9、15、21時)発表する天気図で、 気象庁の担当海域(赤道〜北緯60度 東経100度〜東経180度) における警報事項(海上台風、海上暴風、海上強風、海上風、 海上濃霧)や、陸上や海上の観測データ(気温、風向風速等) を英語や記号で表記している。日本を中心に、フィリピン、中 国東岸、北太平洋をカバーしている。

15 アスファルト アスファルトコンクリートの塊。コンクリート塊

galvanic anode method A galvanic anode system for corrosion protection of steel, comprising a solid electrolyte and galvanic anode material stuck to or embedded in the solid electrode, preferably zinc. The corrosion protection is achieved by reducing electric potential of the steel to the magnitude whereby no corrosion is developed.

blue tide

A phenomenon where the sea surface turns whitish blue or green. It happens in summer or early autumn when oxygen-poor water at coastal sea bottoms is carried upward by the current. This phenomenon has an adverse impact on the fishing industry.

red tide

An event where phytoplankton grow and accumulate rapidly and form dense and visible reddish brown patches near the water surface.

shallow foundation

A foundation having a width-depth ratio of less than 1.0. Terzaghi's theory of shallow foundation can be applied. Nowadays it is a synonym for the direct foundation without piles.

Asian weather chart

A weather chart published by the Japan Meteorological Agency four times (3,9,15 and 21 hours) a day. The chart covers the area between the north latitude of 0 and 60 degrees and between the east longitude of 100 and 180 degrees including Japan, the Philippines and the eastern part of China and the north pacific ocean. It indicates warnings of storms and foggy area together with weather observation data measured on land and sea such as temperature and winds.

asphalt concrete module A lump of asphalt concrete.

あ

- 16 **アスファルト** 単にアスファルト舗装とも呼ばれる。骨材をアスファルトで結 コンクリート 合して作ったアスファルト混合物を表層に用いる舗装をいう。 一般に表層、基層および路盤からなる。
- 7スファルト 乳化剤と安定剤とを含む水中にアスファルトを微粒子として分乳剤 散させた褐色の液体。散布後水分が蒸発し、アスファルトが残る性質を利用して、簡易舗装、防水層等に用いる。
- 18 **アスファルト** 瀝青安定処理のうちアスファルトを結合材として用いた安定処 **の安定化** 理をいう。常温混合方式と加熱混合方式がある。
- 19 アスファルト アスファルト合材の中に補強芯材等を埋め込んで形成した厚さマット10 cm程度のマット。
- 20 アスペリティ 地震時に特に大きくずれて強い地震波を出す領域。
- 21 **頭付きスタッ** 合成桁のようにコンクリート版と鋼桁とを一体化させるための ド ずれ止めで、スタッドともいう。頭付きの丸棒状のもので溶接 により鋼桁の上フランジに植え付ける。
- 22 **圧縮回数依存** 圧縮を受けた回数によって変化する土の性質。 **特性**

asphalt concrete pavement

It is often simply called "asphalt pavement". The pavement with a surface layer made of a mixture of crushed-stone, sand and asphalt. This pavement is composed of a surface layer, a base course and a sub base course.

asphalt emulsion

An asphalt emulsion is a brownish liquid that consists of basic ingredients of asphalt, water and an emulsifying agent. On some occasions the emulsifying agent may contain a stabilizer. The water in the asphalt emulsion evaporates after spreading, while the remaining asphalt is used for a surface treatment or a water proof layer.

asphalt stabilization

The stabilization of crushed stones using asphalt. There are two mixing methods: normal and hot asphalt mixture.

asphalt mat

Approximately 10cm thick mats made of asphalt mixture with reinforcing materials inside.

asperity

An area where bed rock slips internally and develops strong earthquake waves.

stud shear connector Shear connectors embedded in concrete floor slabs or in concrete-enclosed columns for composite frame construction of concrete and steel beam. It is a round shape with a head and welded on the flange of the beam.

compression characteristics

Such a characteristic nature of soil that changes due to the frequency of the frequency-dependent experience of compression.

あ

23 **圧縮指数** 土の圧縮性を示す指数。圧縮試験で得えられた粘土の「e- $\log P$] 曲線における圧密降伏応力以上の直線部分の勾配 $\triangle e/\triangle (\log p)$ で表す。記号は C_o , e は間げき比、Pは圧力。

24 圧入率 砂杭工法において、原地盤に押し込むべき砂の量。

25 **圧密係数** 圧密理論から導かれる圧密速度を支配する土質定数。体積圧縮係数 m_{ν} と透水係数kを用いて、圧密係数 C_{ν} は次式で定義される: $C_{\nu}=k/m_{\nu}\gamma_{\nu}$ の密度)。

26 **圧密降伏応力** 粘土が弾性的圧密挙動を示す領域から塑性的挙動を示す領域に 移行する境界の応力。 "e-logP" 曲線の勾配の急変するとこ ろでの応力。新しい沖積粘土では過去において受けた最大応力 (先行圧密応力) にぼぼ等しい。

27 **圧密試験** 土の圧密特性を求める試験。荷重と圧縮量の関係や圧縮量と時間の関係を測定する。

28 **圧密沈下** 圧縮による体積の減少に伴い土が沈下する現象。土粒子は非圧 縮性とし、沈下は粘土内の間隙水の排出に伴う変化として捉え る。

29 **圧密度** 圧密におけるある時点での圧縮量と最終圧密量の比あるいは百分率。

compression index

A characteristic index of the compressibility of soil. The gradient $\Delta e/\Delta$ ($\log p$) observed in the range beyond consolidation yield stress in the "e-log P" curve of clay. Symbol is C_c , e and P denote the void ratio and the pressure respectively.

sand supply rate

Volume of sand needed to replace the original soil in the practice of the sand pile.

coefficient of consolidation

A constant C_v to characterize the rate of consolidation introduced by consolidation theory defined by the following equation: $C_v = k/m_v \gamma_w$, where m_v is the coefficient of volume compressibility, k is coefficient of permeability and γ_w is density of soil.

consolidation yield

stress

A critical stress where the behavior of soil changes from elastic to plastic. The stress observed at the point where the gradient of "e-log P" curve shows a sudden change. The stress is almost equal to the stress that the soil experienced before.

consolidation test

A soil test that is conducted to examine the consolidation characteristics of soil. The test observes the load-settlement and settlement -time relationship.

consolidation settlement A phenomenon that soil is settled due to the volume reduction caused by compression. This phenomenon is theoretically analyzed with the assumption that the soil particles do not shrink and that the settlement occurs due to the drainage of the pore water in the clay.

consolidation rate

A ratio or percentage of the shrinkage of soil by consolidation at a certain time to the final settlement.

あ

土が圧密するときの特性。圧密圧力と沈下量の時間変化曲線、 30 圧密特性 コンシステンシー特性、圧縮指数 C。圧密降伏応力 p。、体積圧 縮係数m。圧密係数 C。など。 圧密排水三軸 三軸圧縮試験機を用いておこなう圧密試験、供試体の軸方向と 31 側方向からの圧力を加えると共に供試体の周面にろ紙を巻い 圧縮試験 て、側面からも排水させる。 32 **圧力勾配** 管路等における流下方向の圧力の減少率。 33 あてはめ分布 ある物理現象 (例えば波、洪水などの極値) の出現確率分布を 関数 数学的に表示するための分布関数。 前浜に続く陸側の浜。暴風時以外は乾いている。 34 後浜 アノード 電気防食における陽極。電流が陽極から陰極に流れることによ 35 って防食できる。 油回収船 海上に浮遊している油や事故等により海上に流出した油を回収 36 する作業船。 37 アメリカ石油 アメリカ石油協会 は油田における原油生産設備からパイプラ 協会(API) イン輸送、石油製品の製造まで、数多くの規格を定めている。

多くの国が API 規格を採用している。

consolidation characteristics The characteristics exhibited by a soil during the consolidation process. It is often shown as the time variation curve of the consolidation pressure and the settlement, consistency, compression index C_c , yield stress P_c , coefficient of volume compressibility m_v , coefficient of consolidation C_v , and so on.

consolidated and drained triaxial compression test A consolidation test with triaxial compression testing equipment. While the machine exerts the axial and circumference pressure, the pore water of the test piece is drained through filter paper in which the test piece is wrapped.

pressure gradient

The pressure decrease rate in a flow toward the down-flow.

fitted distribution function

A distribution function that mathematically describes the probability distribution of occurrence of extreme physical phenomena such as extreme values of storm waves, floods and etc.

back shore

A zone of beach on the land side of flood tide shoreline. Except during storms, the zone is dry.

anode

An electrode through which positive electric current flows into a polarized electrical device. Electrons flow in the opposite direction to the positive electric current and result in corrosion protection.

oil recovery vessel

A craft that is able to collect oil floating on the water surface as a result of accidents

American
Petroleum Institute
(API)

American Petroleum Institute has established standards of items related to oil drilling, pipelines and products in the oil field. Many countries have adopted API standards.

あ

- 38 アルカリ骨材 骨材中のある種のシリカ鉱物とセメントに含まれるアルカリイ 反応 オンとの間に生じる化学反応。この反応により、コンクリート 内部で骨材の局所的な膨張が生じ、それがコンクリート中にひ び割れを発生させる。
- 39 アルミ合金電 鋼材に取り付けることにより電気防食を行うためのアルミを含極 む金属。
- 40 アレー観測 複数の観測点による地震や波浪の観測。
- 41 **アンカーボル** 防舷材や係船柱などを固定するためにコンクリートに埋め込ま ト れるボルト。
- 42 **安全性** 一般には建設現場における人命にかかわる事故の起こりにくさをいう。設計においては、構造物の作用荷重に対する強度の余裕を意味する。
- 43 **安全性指標** 信頼性指標ともいう。破壊確率に代わる安全性評価のための簡 便な指標。作用荷重や構造材料の強度、その他安全性に影響を 与える要素の不確定性を平均値と標準偏差を用いた安全性指標 が提案されている。
- 44 **安息角** 砂、礫、粉体等の粘着力がない粉粒体の斜面が締め固めしない 状態で安定を保ちうる最も急な傾斜角。

alkali-aggregate

reaction

anode

This is a reaction which occurs over time in concrete between highly alkaline cement paste and non-crystalline silicon dioxide. This reaction may cause local expansion of aggregates that may cause cracks in the concrete.

aluminum alloy

A lump of aluminum alloy to be placed on steel members for cathodic corrosion protection.

array observation

Observations of seismic waves or ocean waves by simultaneous measurement with plural number of measuring apparatus.

anchor bolt

Bolts to fix fenders, bollards, bit, etc. on concrete structures.

safety

In general, the state that the probability of occurrence of accidents that may lead to the loss of life is low. In the designing of structures, this means that the strength of a structure is sufficient against the loads exerting on the structure.

safety index

This is also called the reliability factor, which is simpler index than the failure probability to assess the safety of structures. Several indices are proposed on stochastic approaches on elements affecting the safety of a structure such as load and strengths of the structural members by means of the mean and the standard deviation of the random variables.

angle of repose

The steepest angle that a slope of sand, gravel or other materials of powder or granular shape can maintain its stability without compaction.

あ

- 45 **安定型廃棄物** 廃プラスティック類、ゴムくず、金属くず、ガラスくず、陶磁 **埋立護岸** 器くず、建設廃材などの産業廃棄物を埋め立てる最終処分場。
- 46 安定処理土 物理的または化学的手段により安定な性質に改良された土。
- 47 **安定数** 波の作用を受ける斜面の被覆石やブロックが安定を保つだけの 重量を有するか否かを判定する式(一般化されたハドソン式) において、石やブロックの形状による安定性の相違を考慮する ための係数。

stabilized waste

A final disposal site for industrial wastes such as plastic, rubber, metal, glass

disposal site and ceramic and construction material wastes.

stabilized soil

Soils stabilized by physical or chemical improving methods.

stability number

A coefficient that is employed in formule such as the generalized Hudson's formula used for the verification of the stability of armor stones and blocks on slope against wave actions. The coefficient indicates the difference of the stability due to the shape of the materials.

•	`
L	١,
v	

- 48 e e log p 曲線 土の圧密試験で得られた圧密圧力 p と間隙比 e の関係を、p を対数目盛にとって描いた曲線。
- 49 **異形矢板** 通常の矢板とは形状が異なる矢板。たとえばセル本体とセル相 互を締め切るアーク部の接合に用いられる T 型矢板など。
- 50 維持管理 構造物に要求される安全性、機能性および耐久性を将来に向かって常時維持して行くこと。
- 51 **維持管理計画** 維持管理を行うための計画を記述した書類。 書
- 52 維持管理性 施設の利用及び想定した作用による施設の劣化損傷に対して、 技術的に可能でかつ経済的に妥当な範囲で修理・補修等を施す ことにより、施設に必要な所要の性能を継続的に確保できるこ とができる性能をいう。
- 53 **維持管理費用** 構造物を通常の使用に供することができるよう、維持、点検、 修理するために必要な費用。
- 54 維持管理レベ 施設全体の維持管理計画に基き、施設を構成する部材の経時変ル 化、点検診断及び維持工事等の難易度、施設の重要度を勘案して施設を構成する部材ごとに設定した維持管理のレベルをいう。

e-log p curve

A curve indicating the relation between e and $\log p$ that is obtained from the consolidation test: p and e denote the consolidation pressure and void ratio, respectively.

deformed sheet

pile

General term applied to a sheet pile having any shape other than ordinary sheet pile. For example, a "T" shape sheet pile that is used for the connection $\frac{1}{2}$

of an arc with the main body of cell.

maintenance To maintain the safety, function and durability of structures toward the

future.

proposal of

maintenance

plan

Documents that describe the maintenance plan.

maintenanceabili

ty

The capacity of the facilities to maintain the required performance continuously by repairing with available technologies and economically appropriate cost when the facilities are deteriorated by the expected use and expected actions.

maintenance cost

The cost needed to keep the facilities operational. Those costs for maintenance, inspection and repair.

maintenance level A level of the maintenance of members composing the facilities considering the time worn of the members, levels of the difficulties of inspection and evaluation, maintenance work, and importance of the facilities in accordance with the maintenance plan for the whole facilities.

い

55 **石黒式** 斜め控え矢板壁の安定性を照査する手法の一つ。矢板壁と斜め 控え杭の間隔は不変であると仮定して、斜め控え杭の根入れ部 を弾性支承上の梁として、曲げモーメントと軸力と算定する式。

- 56 **維持修繕費** 施設がその当初の機能を耐用年数まで保ち続けるのに必要な点 検、調整、補修、部品取替などに要する人件費、材料費など。
- 57 維持浚渫 河川流や波浪により埋没した河口や港内の航路や泊地を規定の水深に維持するため継続して実施する浚渫。
- 58 **異常潮位** 天体運動による天文潮以外の原因による潮位上昇の総称。異常 潮位の発生原因は (1) 高潮を起こす気象擾乱、 (2) 津波を起 こす海底の地殻変動、 (3) 海流の変化、などがある。
- 59 異常波浪 台風や低気圧等の気象擾乱によって生じた異常な波浪。
- 60 **イスバッシュ** 流れに対する被覆石およびブロックの所要重量を与える式。 の式
- 61 **イスバッシュ** イスバッシュが提案した流れに対する混成提の被覆石およびブ**の定数** ロックの所要の重量算定式における、石やブロックのの安定性を示す定数。

Ishiguro's formula

A formula that is used to verify the stability of a sheet pile wall with raking anchor piles. With the assumption that the distance between the sheet pile wall and the raking anchor pile does not change, the bending moment and the axial force are calculated assuming the embedded part of the raking anchor piles are placed on an elastic support.

maintenance and repair cost

Costs needed to keep facilities functioning over their working life. The costs consist of labor for inspection, adjustment, repair and replacement of parts, the cost of materials and personnel expenditure.

maintenance dredging Dredging to maintain the water depth of the navigation channels and basins at river mouths and ports which are subject to siltation by river flow and wave actions

abnormal tide level A general term to denote the increase of tide level due to causes other than astronomical tide. Major causes are (1) atmospheric disturbance which causes the storm surge, (2) change in the crust which causes tsunami, (3) change the ocean current.

extreme wave

Abnormal waves generated by atmospheric disturbance such as typhoons and low pressures.

Isbash's formula

An equation that can estimates the required mass of armor stones and blocks placed on the rubble mound foundation under the action of a flow.

Isbash's constant

A constant to denote the stability characteristics of the rubble and the concrete blocks employed in the equation proposed by Isbash to determine the required mass of the rubble and concrete blocks for the composite breakwater.

い

62 位相速度 波の位相の伝わる速度。波のある特定の部分が進んでいく速度。 適当に離れた2地点に同種の地震計(波浪計)を置き、得られ た2つの記録波形の山や谷を対応させ、位相速度を求める。

63 磯波帯 一番沖側の砕波点から汀線に至る区域。

64 一次圧密 土の圧密現象において土の圧縮が弾性圧密理論に従う圧密部分。一次圧密の範囲においては、土に加えられた荷重によって 生じた過剰間隙水圧は、圧密の進行に伴い、土粒子間に作用する有効応力に変わっていく。

65 **一軸圧縮強度** 一軸圧縮試験により得られる土の強度。通常、圧縮強度と呼ばれる一方向からの圧縮力が作用するときの強度。

66 一面せん断試 円盤状あるいは直方体の土供試体を上下2つからなる剪断箱に 験 入れ、鉛直方向に直応力を加えた状態で水平方向に剪断して、 剪断強さを求める試験。

67 一様ハザード 性能照査に用いる地震動の大きさおよび波形を確率的に評価す フーリエスペ るために、過去の地震動の記録から、周波数別のスペクトル振 クトル 幅の生起確率分布を求め、この分布系を元に生起確率を与えれ ば、スペクトルの振幅が周波数の関数として与えられる。これ を一様ハザードフーリエスペクトルと呼ぶ。

phase velocity

The velocity of a specific part of propagating wave. The phase speed is observed from the difference of the arrival time of a peak or trough of the wave profile measured by a simultaneous observation with two different wave gauges or seismometers placed at a certain interval.

surf zone

A zone between the farthest wave breaking line at offshore and the shore line.

primary consolidation

During the first stage of the consolidation process, the soil is compressed in accordance with the elastic consolidation theory. This behavior of soil is called the primary consolidation. As the consolidation proceeds, the pore water pressure is transferred to the effective stress exerting between the soil particles.

unconfined compression strength

This is generally called the compression strength. The strength of soil when a compressive load exerts in one direction.

box shear test

A shear test of soil that is used to determine the shear strength. A cylindrical or cubic shape specimen is placed in the shear box, which consists of upper and lower parts that horizontally move in opposite direction to each other under the action of vertical force.

uniform hazard Fourier spectrum

Standardized spectrum of earthquake for the performance verification against earthquake. The uniform hazard Fourier spectrum is formulated in such a manner that the amplitude of each frequency is given as a function of the probability of occurrence based on historical earthquakes. Thus, for a given probability of occurrence, the amplitude of each frequency component earthquake is given from the uniform hazard spectrum.

い

68 **逸散減衰** 構造物の振動エネルギーが地盤に伝達され、波動エネルギーとして消散されることによる減衰。構造物の剛性が大きいほど、地盤への根入れが大きいほど、また振動数が高いほど、その値は一般に大きくなる。

69 逸走防止装置 暴風時の風荷重によりクレーンが走行方向に移動するのを防止する装置。

70 **一定係数法** 浮体の非線形運動方程式を数値的に解く場合、運動方程式における付加質量項および線形減衰項の係数値は浮体の運動周波数の関数となっているため、陽解法では解けない。そのため、係数をある一定値で代表させて解く方法。

71 一般貨物船 コンテナ、バラ荷以外の様々な形状、サイズの貨物を輸送する船。

72 **移動限界水深** 漂砂粒子に作用する波の力、重力、揚力の均衡状態(移動限界)が破れ、砂粒子が動き始める流速(移動限界流速)に対して、 入射波特性が既知のときに一義的に決まる水深。

73 **移動式クレー** 埠頭上を自由に移動できるクレーン。 **ン**

74 移動式荷役機 移動式クレーンが稼動することにより桟橋や埠頭に作用する活 横荷重 荷重。

75 移動床 水理模型実験において水槽内に砂で形成した水底。

radiational damping Dispersion of vibration energy due to the propagation of wave energy to the foundation. The larger the stiffness of a structure, the longer the embedded depth and the higher the frequency of vibration are, the larger the magnitude of damping becomes.

buffer stop

An apparatus to prevent a crane from moving on the rail under strong storm wind.

constant coefficient method Because coefficients for added mass term and the linear damping term in a nonlinear numerical model of the oscillation of a floating body are the function of the frequency of the movement, the movement of the floating body can not be solved explicitly. This is a method to represent coefficients by a certain constant value for solving the equation.

general cargo ship Ships carrying conventional cargoes other than containers and bulk cargoes.

threshold depth of sediment movement Under a given wave condition, the water depth where sand particles of the sea bed start to move due to the imbalance of wave, gravity and lift forces acting on moving sand articles.

mobile crane

A crane that can move around on the wharf.

live load of mobile cargo handling

equipment

A kind of live load caused by the motion of mobile crane working on piers or wharves.

movable bed

Water beds made of sands for the hydraulic model test.

11

76 色温度

高温の物体からは光が発生しその色は物体の温度によって変化 する。このことから温度で光の色を表現することができる。あ る光に等しい色の光を発する黒体の温度をその光の色温度とい う。 color temperature An object with high temperature emits light. The color of the light varies depending on the temperature. Thus the color of light is expressed by the temperature. The color temperature means the temperature of a object that emits a light having similar color to a certain color.

- 77 ウィルソン法 波浪推算手法の一つ。移動性の風域に適用できるよう S-M-B 法 を改良したモデルで、有義波の波高・周期の増大を追跡して行く方法。
- 78 ウインド・セ 海岸に向かって風が吹く場合、海面付近の吹送流により起こる ットアップ 海岸線付近の水位上昇。
- 79 **ウエーブ・セ** 波が沖から岸に進行してくるとき平均海面が沖から砕波点に向 **ットダウン** かうにつれて次第に低減する。これをウェーブセットダウンと いう。平均海面の最大の低下量は砕波点近傍で生じる。
- 80 **ウエーブ・セ** 波が沖から岸に進行してくるとき砕波帯内では波が汀線方向に **ットアップ** 進むにつれて平均海面が上昇する。この現象をウェーブ・セットアップという。
- 81 上田の式 浮体の縦強度を浮体の動揺を考慮して求める計算式。
- 82 **ウェル** 鉄筋コンクリート製等の底のない筒状構造体。底面の掘削を行いながら沈下させ、所定の支持地盤に達してから底盤コンクリートと頂版を打設して基礎とする。オープンケーソンともいう。
- 83 ウェルポイン 集水装置を揚水管と共に地下水面下に打ち込み、ポンプで地下 ト工法 水を吸引することで地下水位を下げる工法。透水性の高い砂地 盤で効果を発揮する。
- 84 **浮き型** 基盤に到達するまで深層混合処理により地盤を改良するのではなく、非改良地盤中に改良地盤が浮いた状態となるような改良方法のこと。

Wilson's method

One of the wave hindcasting methods. The method is an improved model of the S-M-B method to estimate significant wave height and period under the moving fetch.

wind setup

A rise in the sea level due to the wind drift current generated by the wind blowing toward the shore.

wave setdown

As waves propagate from offshore toward the breaker line, the mean sea level decreases. This phenomenon is called the wave setdown. The maximum wave setdown occurs near the breaker line.

wave setup

As waves propagate from offshore to the surf zone, the mean sea level increases in the surf zone. This phenomenon is called the wave setup.

Ueda's formula

A formula that examines the longitudinal strength of a floating body taking into consideration the motion of the floating body.

well

A large cylindrical structure without bottom made of reinforced concrete. The structure is sunk into soil by digging the bottom until it reaches the supporting soil layer where bottom and top concrete plates are constructed to form the foundation for a superstructure. This is also called an open caisson

well point method A method to drain the soil ground by placing drainage pile equipped with a water collecting apparatus into sandy ground and pumping up the ground water. This method is very effective in a high permeable soil ground.

floating type

One of the types of soil improvement. The method is employed where there is no bearing stratum or the level of the bearing stratum is too deep. The improved soil portion is afloat in the original unimproved soil ground.

>	
~	١
- 4	,

85 **浮きクレーン** 浮体の上に搭載されたクレーン。海上工事に用いられる。 箱型の浮体を用いた桟橋で潮差の大きい所に設けられる。 86 浮き桟橋 浮防波堤 水域に浮体を係留して波の侵入を防止する構造の防波堤。一般 87 に周期の短い波に対して効果があり、内海、内湾、湖などで用 いられる。 88 打上げ高 海浜あるいは傾斜構造物上において、平均水面から測った波が 最も高く打ち上がった高さ。 89 打ち上げ波帯 海浜において、波が最も高く打ちあがった地点と波が最も沖側 に引いた地点の間の区域。 コンクリートの打継ぎによって生じる新旧コンクリートの境 90 打継目 目。打継ぎの方向により、水平打継目と鉛直打継目がある。 打戻し締固め 鋼管 (ケーシングパイプ) を振動打ち込みおよび振動引き抜き 91 方式 を繰り返して砂杭を形成する方法。 92 うねり 海上の波長の長い波で普通の波に比べて方向及び周期が安定し ている。 93 埋め込み杭 掘削した地盤中に既製杭を埋め込むことによって設けた杭。

floating crane A crane installed on a floating body. This is used for marine construction

work.

floating pier A box type pontoon that is used for ship berthing where the tidal range is

large.

floating A type of breakwater that consists of floating bodies and their mooring

breakwater system. This type of breakwater is effective only against short period waves

and used in the water area within inner seas, bays or lakes.

wave run-up

height

The highest level of wave run-up on the beach and sloping structures.

swash zone A beach zone between the highest and the lowest lines of wave movement,

i.e. between the highest wave run-up line and the lowest line during

backrush.

construction

ioints

A boundary of the construction joint between the old and the new concrete.

There are two types of joints: horizontal and vertical joints, depending on the

direction of construction.

sand pile

formation by

vibro-driving and vibro-pulling-out One of the sand compaction methods that create sand piles by driving and

pulling-out a casing pipe using a vibro-hummer.

swell Long wavelength ocean surface waves on the sea. Swells are far more stable

in their directions and frequency than normal waves.

bored precast pile A pile that is, instead of being driven, installed in a hole drilled beforehand

in the ground.

う

94 埋立護岸 埋立地の周囲を被覆して埋立材料の流出を防ぐと共に、波浪、越波および高潮から埋立地を防御する施設。

95 **埋立地内水位** 雨水の流入、越波による侵水などのよる埋立地内の水位。埋立 地の施工中および供用時の両方について安定性を検討する場合 に用いる。

96 裏込め材 護岸、岸壁など土留め壁体の安定を図る目的で壁体の背後に配置する材料。通常、砂礫(割り石、砕石)や鉱さいが用いられる。

97 上屋 船舶からの貨物の陸揚げあるいは船積みのために背後地から輸送されてきた貨物の仕分け、包装、仮置き等の目的で港湾のエプロンに接して建てられる建物。保管のための倉庫とは異なり、上屋内の貨物は2、3日しか置かないのが普通。冷凍上屋、危険物上屋など専用のものもある。

98 運河 船を航行させるために開削した人工水路。

reclamation revetment

A structure that forms the perimeter of a reclamation area that prevents filling materials from flowing out and protects the reclamation area from wave action and over topping.

water level in reclamation site

An elevation of water surface of the ground water accumulated inside the reclaimed land area due to the inflow of rainwater and wave overtopping. The elevation is employed for the verification of the stability of revetment during the construction and after the completion of the construction.

backfilling material Material placed immediately back of the reclamation revetments and wharves for the purpose of stabilizing the earth retaining work and walls. Rubble, crushed stone and slag are widely used.

shed

A building constructed behind an apron of the wharf used for sorting, packing and temporary storage of cargoes before loading to or after unloading from ships. Unlike warehouses, the cargoes stay in the shed for only a few days. Specially designed sheds are also provided for frozen foods or hazardous cargoes.

canal

Artificial navigable channels used for the waterways for passage of ships.

え

- 99 **エアークッシ** 艇の下部から直下に空気を放出して空中に浮き、推進用プロペ **ョン艇** ラ (空中) で進行する形の船舶。
- 100 エアークッシ エア・クッション艇を係留し乗客や貨物の乗降に供する施設。ョン艇発着施設
- 101 **影響値** 線荷重や面荷重が地盤に積載された場合に、地中応力 σ を次式 で表したときの係数 I_{σ} , $\sigma=p\cdot I_{\sigma}$, ここに、pは荷重強度である。
- 102 **永続作用** 設計供用期間を通して絶えず施設に作用することが想定される作用であって、時間的変動が平均値に比較して小さい、あるいは一定限界値に達するまで一定傾向で単調に増加あるいは減少する傾向にある作用。
- 103 **永続状態** ひとつまたは複数の永続作用の組み合わせおよび永続作用と変動作用を組み合わせる状態で、主たる作用が永続作用の状態。
- 104 **H形鋼** 断面形状がH型の鋼材。仮設構造物の梁、柱等の主要構造部材として用いられることが多い。
- 105 **AE コンクリー** コンクリートを練り混ぜる際に、AE 剤あるいは AE 減水剤を混和 ト して人為的に内部に微細な気泡(エントレインドエア)を混入 させたコンクリート。

air cushion craft

Aircushion craft, or often called aircushion vehicle (ACV) or a hovercraft, is a craft designed to travel by propellers over any sufficiently smooth surface supported by a cushion of slowly moving high-pressure air ejected downwards against the surface close below it.

berthing facilities

for air cushion

craft

Facilities to dock air cushion crafts and to serve for boarding the passengers and loading/unloading cargoes to/from the crafts.

influence value

A coefficient I_{σ} employed in the estimation of stress σ in the soil when a line load or distributed load exerts on the ground: $\sigma = p \cdot I_{\sigma}$, where p is the strength of the load.

permanent action

An action that is expected to act continuously over the design working life of the facilities, and has such characteristics as the time dependent fluctuation of the magnitude is relatively small compared to a mean value or that the magnitude tends to increase or decrease constantly until it reaches to a certain limit level

permanent state

A state where the dominating action is a permanent state among under such a state that one or combination of plural permanent actions or a combination of permanent and variable actions exert.

H-shaped steel

Steel product having H-shape cross section. It is often used for major members of temporary structures such as beams and columns.

air entrained concrete

Concrete that is produced by mixing AE agent or AE water-reducing agent to contain fine entrained air bubbles.

え

106 ASTM 米国材料・試験協会の略称。同協会は、米国内の工業標準化を

目的として設立された。同協会の発行する規格は、米国の国内

だけでなく多くの国で利用されている。

107 **A 活荷重** 1994年の「道路橋示方書」の改訂で、新しく導入された活荷重

の一つで、市町村道の橋の設計において、大型車の走行頻度が 比較的低い場合に適用される荷重。従来の TL-20 荷重を包括す

る荷重となっている。

108 液状化 飽和した緩い砂等が地震等による激しい繰返しせん断応力を受

けることによって、粒子の噛合せが外れ、間隙水圧が上昇して 有効応力が減少し、せん断強さを失う現象。粒子が間隙水の中

に浮いた状態となる。

109 液状化対策 地震による液状化の発生を防止する対策。

110 液状化抵抗 繰り返しせん断を与えた時に有効応力がゼロになるか、せん断

ひずみ振幅がある値に達し液状化したと判定されたときのせん

断応力の振幅値。繰り返しせん断抵抗とも言う。

111 液状化予測 想定した地震のもとに対象とする地盤が液状化するか否かを推

測すること。

ASTM

Abbreviation of the American Society for Testing and Materials, which was established for the purpose of standardization of industrial products and materials. The standards issued by ASTM are also employed in many countries outside the U.S.

A-live load

A live load that was introduced in the revision of "the Specification for Highway Bridges" in 1994, and that is employed for those bridges along municipal highways where the traffic of heavy vehicles is minimal. It covers the T-20 load prescribed in the former specification.

liquefaction

This is the behavior of loose saturated sands which go from a solid state to a heavy liquid or reach a liquefied state as a consequence of increasing pore water pressures, and thus decreasing effective stress, induced by their tendency to decrease in volume when subjected to cyclic loading (e.g. earthquake actions).

liquefaction countermeasure works Countermeasures to prevent the ground from being liquefied under earthquake actions.

liquefaction resistance The amplitude of a shear stress, under the action of cyclic shearing forces, that makes the effective stress zero or that makes the soil liquefied when the amplitude of a shear stress reaches a certain limit. It is also called the cyclic shear resistance.

prediction of liquefaction

An evaluation on whether the ground of interest would be liquefied under the action of expected earthquake. え

112 液性限界

細粒子のコンシステンシー限界の一つで、練り返した土が塑性 状態と液状の境界にあるときの含水比。液性限界の値は土中の 粘土鉱物の種類と量、および有機物含有量等に影響される。塑 性指数と共に、細粒土の分類の指標に用いられる。

113 SRC 構造

鋼骨と鉄筋コンクリートの特性、すなわち、耐久性、耐火性、 一体性と、鉄骨構造の粘り強さとを併せ持つ構造。

114 SALM 型

沖合いの石油荷役に使われる係留施設で、海象条件のきびしい 海においてもタンカーが荷役可能である。海底のシンカーにユニバーサルジョイントで繋がれた塔型のブイとフレキシブルパイプから成っている。

115 SMB 法

波浪推算法の一つ。風速、風域が一定の下で発達する波の有義 波高、周期が算定できる。

116 S 型地盤

杭の地盤反力と杭の変位の関係を「港研方式」を用いて算定する場合の、地盤の特性による分類。S型地盤とC型地盤があり、S型地盤は標準貫入値Nが深さと共に直線的に増加する地盤で、一様な砂地盤あるいは正規圧密の粘土地盤である。C型地盤とは標準貫入値が深さ方向に一定値である地盤で、表面が締まった砂地盤あるいは大きな先行圧密を受けた粘土地盤である。

liquid limit

One of the consistency limits of soil. Liquid limit is the water content when the soil is at transition state from plastic to liquid. The value of the liquid limit varies depending on mineral composition and the content of organic materials. Together with plastic index, the liquid limit is used as the index for the classification of fine soils.

SRC (Steel

Framed Reinforced

Concrete) structure

A structure made of steel frame and reinforced concrete. The structure has preferable characteristics of both steel frame and reinforced concrete such as durability, fireproofness, integrity and persistency.

SALM(Single

Anchor Leg

Mooring) type

A mooring facility dedicated to the offshore petroleum discharge system. Once installed, it permits a tanker to remain on station and pump oil in much higher sea states. A SALM system consists of the following main components; upright type buoy body, universal joint, chain with chain swivel flexible pipe and sinker.

SMB (Sverdrup-Munk

-Bretschneider) method

One of the wave hindcasting methods. It estimates significant wave height and period under the stationary fetch.

S-type ground

Classification of ground when the relationship between resistant force of the ground and the displacement of a pile is estimated by "Koken Method, (PHRI Method)." Grounds are classified into S-type and C-type. S-type ground is such a ground that N-value increases proportional to the depth such as uniform sand layer or normally consolidated clay, while C-type ground shows constant N-value regardless of depth such as well compacted sand on the surface and clay layer experienced large consolidation load.

117 **SCP 工法** 地盤改良を目的として施工される砂杭を形成することで基礎地盤の強度を増す手法。緩い砂層の液状化防止対策や軟弱地盤の改良に用いられている。

118 **S₂潮(主太陽** 潮汐を起こす要素のうち太陽の引力により1日2回の干満を起 **半日周潮**) こす要素。

119 越波 海岸堤防、埋め立て護岸、防波堤などの天端を波が越えて背後に流入する現象。

120 **越波(流)量** 越波により持ち込まれる水量(通常 護岸・防波堤の長さ1m あたり1秒あたりの越波量(m³)で表す)。

121 越波流量算定 越波量を図式で求めるための計算図表。

図表

122 **M**g値 防波堤マウンドの石や被覆材の所要重量を算定するのに用いられるハドソン式の安定定数。

123 **V値** 標準貫入試験によって求まる地盤の相対的な硬さ、締まりの程度を表す値。質量 63.5 kgのハンマーを 75 cmの高さから自由落下させ、サンプラーを 30 cm貫入させるのに要する打撃回数で表す。

124 **//値の補正** 地盤の液状化の判定を行う際に、細粒分(粒径が75μm以下の成分)を5%以上含む土層について、N値の補正を行うこと。

SCP (Sand Compaction Pile)

method

A method to construct sand piles underground for the purpose of soil improvement (i.e., increasing the strength of the foundation soil). The method is often used as a countermeasure against liquefaction of loose sand

and the improvement of soft soil.

 S_2 constituent A constituent of tide that describes semi-diurnal tidal motion caused by the

gravity of the sun.

wave A phenomenon where waves jump over seawalls, reclamation revetments

overtopping or breakwaters.

overtopping The volume of water brought in by wave overtopping. Generally, this is

expressed in terms of the discharge rate in m³ per second and per unit length

of the seawall, revetment or breakwater.

overtopping A diagram to estimate the overtopping discharge rate.

discharge diagram

discharge rate

 $N_{\rm S}$ value

A stability number employed in Hudson's equation to estimate the required

mass of armor units or rubble mound for breakwaters.

N-value An index to denote the relative hardness and degree of compaction of

ground. *N*-value is the number of blows that is needed for the sampler to penetrate by 30cm under the condition that the sampler is struck by a weight

having a mass of 63.5kg from height of 75cm.

correction of

N-value

To correct the *N*-value of soil in verifying liquefaction of ground, when the percentage of the fine grains having size of 75μ m and less is 5% or larger.

_
-
_
/

- 125 エネルギー平 不規則波の周波数スペクトルの浅海域における屈折による変化 **衡方程式** を計算し、浅海域の波高変化を算出する式。
- 126 FRP 被覆 FRP を用いた被覆。
- 127 **FCL 貨物** コンテナ全体の貨物が同一荷主である貨物。
- 128 エプロン 埠頭の水際線から上屋あるいはヤードに至るまでの平坦な場所 で、船舶への貨物の積み卸しのための仮置き、搬出入、荷役の ための車両や荷役機械の走行等に必要な空間。
- 129 エプロンエリ エプロンおよびその周辺を含む区域。 ア
- 130 **MRI モデル** 気象研究所が開発したスペクトル法による波浪推算数値モデル。
- 131 **M**₂**潮(主太陰** 主要4分潮の1つで月の運行によって生じる周期12時間25分 **半日周潮**) の分潮。
- 加,法 圧密沈下量を求める方法のひとつ。体積圧縮係数を m,として、 圧力増分 △pによる最終圧密沈下量 Sが S=m, △p・hで与えられる。 hは層厚。

energy balance

equation

An equation to estimate the variation of wave height in shallow water in calculating the variation of the spectrum of random waves caused by reflection.

FRP (Fiber

A lining using the fiber reinforced plastics.

Reinforce

Plastics) lining

FCL (Full

Cargo stuffed in one container of which shipper or consignee is the same

Container Load)

cargo

company.

apron

A flat area between the sea side edge of a wharf and a shed or storage yard. The area is paved and used for loading and unloading cargoes to and from

ships and for traffic of vehicles or cargo handling equipment.

apron area

An area that includes the apron and adjacent areas.

MRI

A numerical model for the wave hindcasting developed by the

(Meteorological

Research

Institute) model

Meteorological Research Institute.

M₂ constituent

One of the tidal constituents. M_2 is called the principal lunar semi-diurnal component having a period of 12 hours and 25 minutes, which is caused by

the motion of the moon.

 m_{ν} method

One of the methods to estimate the consolidation settlement. The final consolidation settlement due to the pressure increment of Δp is given by $S=m_v\Delta p\cdot h$, where S: final consolidation settlement, m_v : coefficient of volume compressibility, h: the depth of soil layer.

133 L 荷重 道路橋の主桁を設計するために用いられる自動車が連なって通 過することを想定した活荷重。 134 **L型棚** L字型をした棚式係船岸の上部工。 **L型ブロック** 鉛直の壁と底版および壁を支えるバットレスを一体として製作 135 したコンクリートブロック。 136 **L型ブロック** L型の形状をしたコンクリートブロックを使用した型式 式 L型プロック L型のコンクリートブロックを設置し、その背後を埋め立てて作 137 式岸壁 られる岸壁。 138 LNG 船 液化天然ガス (LNG)を輸送する専用船。 液化石油ガス (LPG)を輸送するタンカー。 139 **LPG 船** 140 エルボ 送油管等、管路の屈曲部分に使用する部材。送油間が海中から 陸上部に立ち上がる部分の構造では、海底地盤の沈下に対応で きるよう変位を許容する構造とするため、エルボと呼ばれる部 材を使う。 141 塩害 鉄筋コソクリート中に取り込まれた塩分が、鋼材を腐食させる ことにより、コンクリートに損害を与えること。

L-load A live load for the design of the main beam of highway bridges. The load

assumes such situation that a line of vehicles are passing on the bridge.

L-shaped An L- shaped reinforced concrete superstructure of the quaywall with

relieving relieving platforms.

platform

L-shaped block A reinforced concrete block made of vertical wall, floor slab and wall

supporting buttress combined together.

L-shaped block A type of structure composed of L-shaped blocks.

type

L-shaped block A quaywall that consists of L-shaped blocks with a reclamation behind

type quaywall them.

LNG (Liquefied A special ship to carry liquefied natural gas.

Natural Gas)

carrier

LPG (**Liquefied** A tanker that is designed for the transportation of liquefied petroleum gas.

Petroleum Gas)

carrier

elbow A unit of pipe that is used at the bend of a pipe line. An elbow pipe is used to

absorb the anticipated displacement of a pipe at the landing point from the

sea due to seabed subsidence.

salt injury Damage to reinforced concrete members of structures caused by corrosion

of reinforcing bars due to salt.

142 **沿岸漂砂量公** 沿岸漂砂量の算定式。 式

- 143 沿岸海流 海浜流より少し沖側に存在する風や潮流によって生じる流れ。
- 144 沿岸砂州 ある特性の波が長時間作用すると海浜はその波の特性と底質粒径に対応した平衡断面に近づく。この平衡断面には沖合いに砂州が発生する場合としない場合があり、前者をバー型海浜、後者をステップ型海浜と呼ぶ。
- 145 **沿岸帯** 満潮江線から干潮江線までの区間を主に生物学的観点から沿岸 帯というが、もう少し深い所まで含めることもある。
- 146 沿岸堆積 漂砂現象によって砂などが沿岸に堆積すること。
- 147 **沿岸漂砂** 砕波帯内の波による砂の移動のうち、汀線と平行方向に移動するものを沿岸漂砂と呼ぶ。汀線と直角方向の漂砂を岸沖漂砂という。

formula of

longshore

A formula to estimate the longshore sediment transport rate.

sediment

transport rate

coastal current

A current observed at the offshore side of the surf zone and generated by

wind and tidal motion current.

longshore bar

Under a wave action over a long period of time, the beach transforms its profile until it reaches an equilibrium profile that corresponds to the characteristics of waves and diameter of sediment. The equilibrium profile of a beach sometimes has an offshore sand bar. The profile with an offshore bar is called the bar-type beach, while the profile without an offshore sand

bar is called the step-type beach.

littoral zone

A zone between the shorelines of high water and low water. This term is mainly used from the biological and ecological viewpoints and sometimes denotes a wider zone beyond the shoreline at low water.

littoral

A phenomenon whereby sediments accumulate along the shore.

accumulation

longshore

Transport of littoral drift along the shore is called alongshore sediment

sediment

transport, while that perpendicular to the shore is called on shore-offshore $\,$

transport sediment transport.

countermeasure

against longshore

A countermeasure to prevent alongshore sediment transport from occurring.

sediment transport

沿岸漂砂量 汀線と平行方向に移動する単位時間あたりの漂砂量を沿岸漂砂 149 量という。通常はm3/年の単位で表現する。 汀線に斜めに波が入射する場合に、汀線近くに発生する汀線と 150 沿岸流 平行方向の流れで、砕波点より少し岸側で最大流速を示す。 円球型 係船ブイの形状の一つ。円球型のほかにコマ型、平円盤型、な 151 し(梨)型、円すい型などがある。 斜面等が円弧状のすべり面によって破壊する現象。円形すべり 152 円弧すべり ともいう。斜面の長さが有限な粘性土に生じることが多い。 円弧すべり解 円形すべりの発生の有無を解析すること。 153 析 **円周方向応力** 鋼管等の円周方向の応力。 154 度 遠心力鉄筋コ 遠心力締め固めによって製造された中空円筒形断面の鉄筋コン 155 **ンクリート杭** クリート杭。 156 **遠心力模型実** 遠心力載荷装置を用いて地盤の縮尺模型に大きな重力加速度を 験 加えて行なう実験。模型の自重応力が実物と一致するため、相 対的な変形・破壊の挙動を予測することが可能となる。 157 **円すい型** 係船浮標に用いられる浮体の形状タイプの一つ。底面が円錐状 になっている。

longshore The volume of littoral drift moving parallel to the shore. The volume is

sediment usually expressed in terms of m³/year.

transport rate

longshore A current parallel to the shore that is formulated when the incident waves

currents reaching the shore are diagonal. The maximum velocity of the longshore

current is observed on the onshore side of the breaker line.

sphere type One of the mooring buoy types. In addition to sphere type, there are

spinning top type, discus type, pear type and cone type.

circular slip A phenomenon whereby a slope collapses by slipping along a circular face.

failure It is seen on clayey slopes with finite lengths.

circular slip Analysis to judge whether a circular slip failure occurs or not.

failure analysis

circumference A stress occurs on the circumference direction of the steel pipe.

stress

reinforced A factory fabricated cylindrical reinforced concrete pile with a hollow inside

spun-concrete produced with the use of the centrifugal force during the compaction

pile process of the concrete.

test

centrifugal model A model test to examine relative deformation and failure of soil utilizing

centrifugal loading equipment that can control gravitational acceleration so

that the similarity of self-weight of soil is fulfilled.

cone type A type of buoy used for mooring buoys. It has a cone shaped bottom.

_
~
_
/ _

158 塩水楔 感潮河川域において海水と河川水の密度差により河川水の下を 海水が楔状に遡上するもの。 **鉛直支持力** 杭等の鉛直方向の支持能力。 159 鉛直排水法 地盤の圧密を促進するために軟弱粘土地盤中に人工的に鉛直な 160 排水路を造ることで、排水を促進し、圧密時間を短くする方法。 161 **鉛直方向圧密** 土の間隙水が鉛直方向に排水する場合に用いる圧密係数。 係数 鉛直方向地盤 鉛直方向に地盤に載荷したとき、応力(地盤反力) pと沈下量 S 162 **反力係数** の間に $p = k_s S$ が成り立つと仮定したときの係数 k_s 。 エンドストッ 岸壁のクレーンの軌道の端部に設置する暴走止め。 163 パ 164 **エンドストッ** エンドストッパーを固定するための十台となる金具。 パ基礎金具

salt water wedge A phenomenon whereby sea water intrudes into the lower layer of a river

due to the difference in density.

vertical bearing

capacity

A vertical bearing capacity of piles etc.

vertical drain A method to quicken the consolidation of soil underground with an artificial

method vertical drainage.

vertical A coefficient of consolidation which is employed for the case that the pore

coefficient of water is drained in the vertical direction.

consolidation

coefficient of A coefficient k_s under the assumption that the stress p and displacement S is

vertical subgrade proportional, i.e., $p=k_s S$, when a vertical load acts on the ground.

reaction

end stopper A stopper installed at the end of crane tracks on wharves to prevent

derailing.

metal fitting for Base apparatus for fixing the end stopper.

base of end

stopper

165 **応答スペクト** 波浪や地震動が作用した時の構造物の振動の周波数スペクト ル ル。

166 **応答変位法** 埋設パイプラインや沈埋トンネルなどのように見かけの単位体 積重量や剛性が小さく、延長が長い構造物では、その存在が周 辺地盤に及ぼす影響が小さいので、地震時に地盤に生じる変位 や変形と同じように施設にひずみが生じるものと仮定して変位 や応力を解析する方法。

167 **応力集中係数** 応力集中を生じている箇所の最大応力値と基準とする応力値と の比。基準とする応力値は応力集中箇所から離れた一様応力場 の値を用いることが多い。

169 **応力分担比** サンドコンパクションパイル工法において砂杭と砂杭間の粘性 土が受け持つ応力の比。応力分担比nは μ_c = $\Delta C_s/\Delta C_c$ (ここに ΔC_s は対象とするすべり線位置での砂杭部分での鉛直応力増分、 ΔC_c は対象とするすべり線位置での砂杭間粘性土部分での鉛直応力増分。

170 **応力分散法** 地面に載荷した荷重がブーシネスク法等によって地中に分散するとして安定解析をする方法。

171 **0**₁**潮(主太陰** 主要4分潮の一つ。月の引力によって励起される一日周期 **日周潮**) (25.819 時間)の潮汐成分。 response

A spectrum of the frequency response on vibration motion of a structure

spectrum

against ocean waves or seismic waves.

response displacement method A method to analyze displacement and/or stress of long laying structure based on the following consideration. For the case of pipelines and immersed tunnels, it is assumed that the displacement of these structures is the same as that of the ground displacement, since the effects of the stiffness of the structure are too small to give any effects on the surrounding ground.

stress concentration coefficient The ratio of the maximum stress at the location where the concentration of stress occurs and the reference stress. The reference stress corresponds to the stress observed at the locations away from the location where the concentrated stress occurs and the magnitude of the stress is adopted from a uniformly distributed stress field.

stress reduction coefficient A stress reduction coefficient μ_c is given as the ratio of the increment of the stress of the sand pile ΔC_a and the increment of the stress of unimproved soil ΔC_c , i.e., $\mu_c = \Delta C_c / \Delta C_a$.

stress sharing

The ratio of the stresses shared by the sand piles and the soils between the sand piles of sand compaction pile method. The ratio of stress share is $\mu_c = \Delta C_s / \Delta C_c$, where ΔC_s is the increment of the vertical stress of the sand piles at the location of sliding surface, while ΔC_c is the increment of that of the unimproved soil between the sand piles at the sliding surface.

stress distribution method

An analysis method of ground stability under the load on the surface of the ground taking into consider the distribution of stress in the ground by such method as Bousinesq method.

O₁ constituent

One of the principal tidal constituents. A O_1 is called the principal lunar diurnal tide caused by the gravity of the moon. The period is 25.819 hours.

- 172 大型三軸圧縮 大容量の三軸圧縮試験。三軸圧縮試験は、地中における荷重状 試験 態を再現するため、試験試料に側圧を作用させながら圧縮試験 を行う試験法。 大潮平均高潮 平均水面上、M。(主太陰半日周潮) とS。(主太陽半日周潮) の振 173 面 幅(半潮差)の和に相当する高さ。 174 大潮平均低潮 平均水面下、M。(主太陰半日周潮) とS。(主太陽半日周潮) の振 面 幅(半潮差)の和に相当する高さ。 175 大潮升 基本水準面から大潮の平均高潮面までの高さをいう。 176 大島式 斜め控え杭矢板壁の性能照査をおこなう簡易方法の一つ。 オーバーラッ 深層混合処理工法によって形成された安定処理土の重なり合う 177 プ部 部分。 178 置き(鋼板) 鋼矢板あるいは鋼板を円形等に閉合させたセルを海底に設置し セル た後十砂等で中詰めをおこなった構造物。
- 179 置き(鋼板) 連続して建設した置きセルを下部構造とした岸壁。 セル式岸壁

large-scale tri-axial compression test A large scale tri-axial compression test which is a kind of compression test on soil specimens conducted by applying circumferential pressure in the manner that the stress condition on the soil specimen is in conformity with the in-situ condition of the soil

high water of ordinary spring

An elevation of sea level as high as the sum of the amplitudes of M_2 (principal lunar semi-diurnal component) and S_2 (principal solar semi-diurnal component) component above the mean sea level.

tides (HWOST)

tidal rise at

The vertical distance between the datum level to the mean high water level of spring tides.

ordinary spring tides

One of the simplified methods to verify the performance of sheet pile formula quaywall with batter anchor piles.

overlap portion

The portion where adjacent deep cement mixing improved sections of soil overlap each other.

placement-type steel plate A large cylindrical structure made of steel plate or steel sheet piles placed on the sea bed with earth fill in it

cellular-bulkhead

A quaywall having a foundation made of continuously placed steel plate cellular units.

-52-

steel plate cellular-bulkhead quaywall

placement-type

180	沖波波高	海底の影響を受けない深海の波の波高。
181	沖荷役	ブイへの係留又は錨泊の状態ではしけ利用により貨物の積み卸しをすること。
182	沖浜帯	通常の波の砕波線より沖側の区域。
183	沖浜流	砕波帯の外側を流れる潮流以外の流れで海岸に平行のことが多い。
184	押さえ盛土	盛士等の土構造物が安定性を失って破壊を生じる恐れがある場合、滑る危険性の高い側に作られる盛土。
185	押抜きせん断	コンクリートや金属の板材に集中荷重が加わる場合、荷重周辺の板の狭い範囲に局部的なせん断応力が発生する現象。 桟橋に水平力が作用したとき、杭の抵抗力が梁に対する集中荷重として働く。ケーソンをジャッキで持ち上げるような場合、ジャッキが集中荷重としてケーソンに作用する場合に作用する。
186	押抜きせん断 破壊	集中荷重の作用によって発生した押し抜きせん断力により、版の狭い範囲がコーン状に抜け落ちる局部的な破壊現象。
187	オスターバー グ	台形分布の荷重に対する地盤の応力算定式を提案した研究者。
188	汚濁防止膜	浚渫区域、余水吐のまわり等を遮蔽して二次汚染を防止する可搬式の障壁。

 ${\bf deepwater\ wave}$

height

The wave height in the deep sea where the waves receive no effect from the

sea bottom.

offshore cargo

handling

Cargo handling performed at the anchorages between ships anchored at a

buoy or by own anchor and barges.

offshore zone

A water area on the offshore side of the furthest breaker line.

offshore current

A current other than tidal current that occurs outside of the surf zone. It often

runs parallel to the shore.

counterweight fill

An embankment that is constructed at a site in danger of sliding as a

counterweight to prevent the slope from sliding.

punching shear

A local shear stress that occurs in the vicinity of the load when a

concentrated load acts on a concrete slab or steel plate. This type of shear occurs in the concrete beams of piers when a horizontal force acts on the pier, since the resistance force of the piles acts on the beam as a concentrated load. Another instance of the concentrated load is the case that a concrete

caisson is lifted by jacks.

punching shear failure A phenomenon of a local cone shaped failure due to a punching shear

caused by the action of a concentrated load.

Osterburg

A researcher who proposed a formula to calculate the stress distribution in

the ground under the action of a load distributed in trapezoidal shape.

silt fence

A portable barrier that is stretched around the turbidity area by dredging or

the spillway of a reclamation to prevent a secondary contamination around

the water area.

お

189 汚泥 汚濁された泥分。下水処理による廃棄物として発生する下水汚泥あるいは汚濁懸濁物質が海底等に堆積した結果生じる堆積汚泥がある。

190 汚泥浚渫船 汚泥を浚渫するために二次汚染を少なくし、高濃度の浚渫が可能なように特別に設計された浚渫船。

191 ω^2 モデル 地震動の震源特性(加速度、速度、変位)を表すモデル。 ω^2 モデルに従う加速度震源スペクトルはコーナー周波数 f_c よりも低周波側では周波数の自乗に比例し、 f_c よりも高周波側では一定となる。

192 **オランダ式二** 一般的にダッチ・コーンと呼ばれる代表的静的サウンディング **重管コーン貫** 法で、先端抵抗と周面摩擦を分離して測定できる。 入試験

193 折返し回折図 港内侵入波の解析手法の一つで、港口からの進入波に対する港 大回折図で与え、岸壁や護岸の位置で回折図を折り返したもの が反射波と仮定して侵入波と重ね合わせる方法。

194 音響測深機 観測船に取り付けた超音波発信機により水中に超音波を発信 し、海底面からの反射音がもどってくるまでの時間から水深を 測定する機器。

sludge

Sludge is the semi-solid material left from water treatment, or waste water treatment processes or sediment of contaminated suspended material.

bottom sediment dredger A dredger specially designed to efficiently dredge sludge at the surface of the sea bed without disturbing the sea bed or creating a secondary contamination.

omega-square model A model to explain the characteristics of an epicenter, i.e., acceleration, velocity and displacement. The ω^{-2} model gives such profile of seismic wave spectrum that the spectrum density is proportional to the square of the frequency over the frequency range lower than the corner frequency f_c , while it remains at a constant level over the frequency range higher than f_c .

Dutch cone penetration test The most commonly used static sounding method. By penetrating the cone shaped probe called the Dutch cone, the base bearing capacity and the shaft resistance are measured separately.

superposition method for wave diffraction analysis One of the methods to analyze the diffraction of waves invading in the port through the port entrance, i.e., the opening of the breakwaters. The diffraction chart is drawn for the invaded waves from the port entrance. At the face lines of the wharves, the diffraction chart is folded back as the reflected waves by the wharves. The wave heights are estimated as the square root of the sum of the energies of the invaded and the reflected waves.

echo sounder

An apparatus to measure the water depths using sound. An apparatus installed on a ship measures the duration between the time a sound pulse is emitted and the time the echo from the sea bottom returned to the receiver. The travel time of the sound is converted to the travel distance by multiplying the sound speed.

お

195 **温度特性** ゴム防舷材は吸収エネルギー及び反力の特性が温度によって変(**防舷材の**) 化する。これを防舷材の温度特性と呼ぶ。

196 **温度補正係数** 温度によって防舷材の特性が変化することを考慮し、標準状態 (防舷材の) (温度) の吸収エネルギーおよび反力特性に対して温度補正を おこなうための係数。

197 音波探査 音波が地層の不連続面で反射するときの音響インピーダンスの変化を測定して地層の境界を調べる方法。

temperature Such a characteristic nature of rubber fenders that the characteristics of a

dependence of rubber fender, i.e. energy absorption - reaction force curve, change

fender depending on the temperature.

temperature A coefficient employed in the correction of the characteristics of rubber

correction fenders considering the temperature dependent nature of rubber.

coefficient of

fender

acoustic

exploration when it is reflected at the boundaries of soil layers.

The method utilizes the nature of the sound in which its impedance changes